



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3744	Drag Click	6795	Counterbalance Cover
0071	Rotor Nut	3747	Slider Retainer Screw	7289	Push Button Collar
0452	Drag Spring Washer	3848	Bail Spring Guide (A)	7290	Push Button
0540	Multi-Purpose Screw	3849	Bail Spring Guide (B)	7295	Ball Bearing
0574	Drag Washer "C" (cloth)	3853	Anti-Reverse Lock Out	7296	Pinion Gear
0579	Eared Washer "B"	3854	Anti-Reverse Lock Out Spring	7297	Anti-Reverse Cam
0584	Hold Click Spring	3855	Lock Out Spring Holder	7298	Anti-Reverse Lever
0642	Side Cover Screw	3856	Anti-Reverse Pawl	7299	Drive Gear
0779	Multi-Purpose Screw	3857	Anti-Reverse Pawl Spring	7300	Oscillating Slider Retainer
0787	Nut Lock Screw	4049	Large Hole Washer	7301	Oscillating Slider Inner
0792	Bearing Retainer Screw	4096	Drag Shaft	7302	Oscillating Slider
0848	Small Hole Washer	4097	Pressure Screw	7303	Oscillating Gear
1008	Handle Lock Washer	4099	Drag Knob Screw	7304	Oscillating Gear Bushing
1891	Bail Spring Cover Screw	4367	Line Roller Screw	7305	Drag Spring
2257	Drag Washer "H" (blue)	4568	Bail Arm	7306	Drag Knob
2283	Anti-Reverse Pawl Screw	5625	Line Roller Spacer	7307	Handle Assembly
2293	Drive Gear Bushing	5628	Line Roller Collar	7309	Spool Assembly
2419	Handle Screw Cap	5629	Line Roller Bushing	7310	Main Shaft
2852	Handle Screw Lock	5630	Line Roller	7311	Bail Assembly
3359	Line Roller Washer	5690	Anti-Reverse Lever Screw	7312	Rotor
3397	Bail Spring	5996	Locking Spring	7313	Body Set
3402	Cover Screw	6787	Bail Spring Cover		
3471	Anti-Reverse Cam Spring	6794	Bail Trip Lever		